



External relay for controlling electric floor heating

Suitable for use with Airobot SE1 24V room sensor.

The relay switches the L (phase wire) electric floor heating cable on the COM/NO (normally open) principle.

Connect:

- Turn off the power supply
- Install a relay in a wall box
- Connect the relay terminals with the designation:
 - o 1 – Electric floor heating L
 - o 2 – Electric floor heating L
 - o 5 – SE1 24V room sensor terminal R-
 - o 6 – SE1 24V room sensor terminal R+

Specifications

Contact	1 x NO/NC
Maximum voltage	16A, 250 VAC
Indicator	Green LED light ON when relay in activated state (heating on)
Cable	Max. 2.5 mm ²
Dimensions	48 x 43 x 25 (height) mm
Installation	EU wall box
Protection class	IP20